

FITTING THE CONTROL KNOB
TO THE
WIPER TIMER ROTARY SWITCH

To fit the control knob on the stem of the rotary switch, gently prise the off the cap & ensure that the brass nut is loose enough to allow the knob to fit onto the stem.

Then carefully tighten the nut until the collet in the knob grips the stem.

(Take care not to over tighten the nut).

