

REMOVING THE MUSHROOM BUTTON FROM THE HAZARD LIGHT PULL SWITCH





In order to fit the switch to your dashboard or bracket the mushroom button must be removed: Hold the switch body & gently twist the mushroom button 1/4 turn anticlockwise. Refitting the mushroom button is the reverse of this operation. (The same method is used if the LED needs replacing).